

ProKure products remove dangerous germs and tough odors (including tear gas and pepper spray) from law enforcement vehicles.

Use the protocols below to disinfect and deodorize all types of law enforcement cars, trucks, buses and other vehicles.



## Equipment Needed

Qty	SKU	Description
1 Each	185-0005B	<b>ProKure V</b> - 24 gram (0.84 oz) Pouch
1 Each	185-1010	<b>ProKure D</b> - 25 gram Fast Release Pouch*
1 Each	123-0029	Black pump sprayer, 2.5 gallon**

\*The 185-1010 **ProKure D** 25 gram Fast Release pouch will deodorize up to approximately 2,250 cubic feet of unoccupied enclosed space (i.e. 22.5'd x 10'w x 10'h). The active ingredient in **ProKure** dissipates faster in sunlight, so more gas generation is required for small windowed vehicles such as squad cars, vans, buses under 15' and truck cabs. For larger vehicles such as buses and command centers, use one (1) **ProKure D** Fast Release 25 gram Pouch per 25' of vehicle length. For example, a 40' bus would require two (2) **ProKure D** Fast Use 25 gram pouches. Use one additional pouch for more difficult or persistent odors such as tear gas and pepper spray.

\*\*2.5 gallons of **ProKure V** will disinfect and deodorize approximately 2 to 3 small vehicles depending on the size of vehicle and application.

## Before You Begin

**Important:** Check manufacturer cleaning protocols and warranty information on all law enforcement gear before using ProKure. Always test ProKure V in an inconspicuous area prior to use. Do not use ProKure V or D with or on any computers, electronics or equipment that can be damaged by water. Read and follow all labels and protocols prior to use. Wear appropriate personal protective equipment at all times. It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

## Protocol 1 of 2: Using ProKure V Liquid

For best results, use ProKure V *before* ProKure D.

1. Fill the 2.5 gallon black pump sprayer with cool tap water.
2. Open the ProKure V 24 gram foil packet and remove inner white pouch. **DO NOT CUT OR OPEN THE INNER WHITE POUCH.**
3. Shake the white pouch several times then insert it into the 2.5 gallon black pump sprayer.
4. Close and tighten the sprayer cap completely. Take care to avoid spillage.
5. The solution will be fully activated and ready to use within 60 minutes.
6. Wash, rinse or wipe off any visible debris on the gear such as dirt, grease, oil, bodily fluids, feces, food, etc.
7. Cover and **DO NOT** spray liquid on computers, electronics or any equipment that can be damaged with water.
8. When ready to use, gently shake the sprayer to ensure complete mixing of solution.
9. Spray surfaces liberally. Soft surfaces such as carpets, headliners, and cloth seats should be sprayed or misted two times to ensure full coverage.
10. Wipe any non-stainless metals, glass and mirrors after application to avoid smears.



## Protocol 2 of 2: Using ProKure D Fast Release Gas

Always Use ProKure D *after* ProKure V.

**Important:** The active ingredient in ProKure dissipates in sunlight. Do not park the vehicle in the sun during the process outlined below. For best results, perform the process in a garage or at night.

1. Remove all contents from the ProKure D plastic clamshell. Do not discard clamshell.
2. Open foil packet and remove inner white pouch. **DO NOT CUT OR OPEN THE INNER WHITE POUCH.**
3. Gently shake the white pouch to start the activation procedure.  
**For Cars and SUVs - follow steps 4-8:**
4. Ensure all vehicle windows and doors are closed. The vehicle **MUST BE UNOCCUPIED** during treatment.
5. Wet sponge with warm water and firmly insert the indented end of the white pouch into the sponge.
6. Place the white pouch attached to the wet sponge back inside the clamshell package and snap the clamshell closed.
7. Place clamshell, with holes facing up and unobstructed, in vehicle on any flat surface, near the center of the vehicle. Ensure holes on clamshell are facing up.
8. Allow the product to circulate in vehicle for at least four (4) hours.

**For Larger Vehicles (Buses and Mobile Command Centers) - follow steps 9 - 13:**

9. Ensure all vehicle windows and doors are closed. The vehicle **MUST BE UNOCCUPIED** during treatment.
10. Place inner white pouch in plastic cup with 1 and 1/2" water; wicking squares should be placed in the water.
11. Place cup in vehicle on a flat surface. **DO NOT** spill liquid in cup after inner white pouch activates.
12. Allow the product to circulate in vehicle for at least four (4) hours.

**OPTIONAL TREATMENT FOR DEODORIZING VENTILATION SYSTEM:** After four (4) hours, quickly enter vehicle, start ignition and turn on re-circulating air (**NOT THE AIR CONDITIONING**). Do not breathe the gas. Leave the vehicle quickly. Leave all windows and doors closed and let vehicle run for 15-30 minutes.

Once treatment is completed, the vehicle must be aerated for at least 1 hour prior to re-entry. Open all windows and doors to accomplish aeration.

